

PoExtBusOC16-CNC

User's manual

Please read the following notes

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice.
2. PoLabs does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of PoLabs products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of PoLabs or others. PoLabs claims the copyright of, and retains the rights to, all material (software, documents, etc.) contained in this release. You may copy and distribute the entire release in its original state, but must not copy individual items within the release other than for backup purposes.
3. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of the products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. PoLabs assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
4. PoLabs has used reasonable care in preparing the information included in this document, but PoLabs does not warrant that such information is error free. PoLabs assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
5. PoLabs devices may be used in equipment that does not impose a threat to human life in case of the malfunctioning, such as: computer interfaces, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment, and industrial robots.
6. Measures such as fail-safe function and redundant design should be taken to ensure reliability and safety when PoLabs devices are used for or in connection with equipment that requires higher reliability, for example: traffic control systems, anti-disaster systems, anticrime systems, safety equipment, medical equipment not specifically designed for life support, and other similar applications.
7. PoLabs devices shall not be used for or in connection with equipment that requires an extremely high level of reliability and safety, as for example: aircraft systems, aerospace equipment, nuclear reactor control systems, medical equipment or systems for life support (e.g. artificial life support devices or systems), and any other applications or purposes that pose a direct threat to human life.
8. You should use the PoLabs products described in this document within the range specified by PoLabs, especially with respect to the maximum rating, operating supply voltage range and other product characteristics. PoLabs shall have no liability for malfunctions or damages arising out of the use of PoLabs products beyond such specified ranges.
9. Although PoLabs endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, PoLabs products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a PoLabs product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures.
10. Usage: the software in this release is for use only with PoLabs products or with data collected using PoLabs products.
11. Fitness for purpose: no two applications are the same, so PoLabs cannot guarantee that its equipment or software is suitable for a given application. It is therefore the user's responsibility to ensure that the product is suitable for the user's application.
12. Viruses: this software was continuously monitored for viruses during production; however the user is responsible for virus checking the software once it is installed.
13. Upgrades: we provide upgrades, free of charge, from our web site at www.poscope.com. We reserve the right to charge for updates or replacements sent out on physical media.
14. Please contact a PoLabs support for details as to environmental matters such as the environmental compatibility of each PoLabs product. Please use PoLabs products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. PoLabs assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
15. Please contact a PoLabs support at support@poscope.com if you have any questions regarding the information contained in this document or PoLabs products, or if you have any other inquiries.
16. The licensee agrees to allow access to this software only to persons who have been informed of and agree to abide by these conditions.
17. Trademarks: Windows is a registered trademark of Microsoft Corporation. PoKeys, PoKeys55, PoKeys56U, PoKeys56E, PoKeys57E, PoExtension, PoScope, PoLabs and others are internationally registered trademarks.

PoExtBusOC16-CNC user's manual

1. Description	4
2. Features.....	4
Installation.....	5
PCB dimensions and mounting holes	9
3. Grant of license	10

1. Description

PoExtBusOC16-CNC is an extension board for driving up to 8 stepper motor signals. It contains 8 standard 10-pin connectors for directly connecting the stepper or servo motor drivers. Each connector provides step, direction and shared enable signals.

Similar device PoExtBusOC16 (without CNC) is designed for providing up to 16 digital outputs and is not compatible as it uses a different wiring scheme. Unlike with PoExtBus devices, only one PoExtBusOC16-CNC can be used and daisy-chaining is not supported.

2. Features

- Up to 8 stepper motor drivers can be connected
- Enable signal for each driver
- PoExtension connector for connecting to master device
- Only one PoExtBusOC16-CNC can be used




Figure 4: PoExtBusOC16-CNC

3. Installation

PoExtBusOC16-CNC uses 6 pins from the PoExtension connector. Use the wiring scheme as shown in Table 1 in case the PoExtension connector is not available on the master device. PoExtBusOC16-CNC is shipped with the cable attached to the PoExtensionIn.

To use PoExtBusOC16-CNC with PoKeys57E/PoKeys57U connect the flat cable to the appropriate pins of PoKeys57E/57U device.

Pin	Description	PoKeys57U pin	PoKeys57E pin
1 (red)	5 V power supply to the PoExtBusOC16-CNC – must supply at least 40mA for correct operation	5 V	5 V
2	PoKeys ground	GND	GND
3	Motor enable signal	Any free I/O pin	Any free I/O pin
8	Signal for pulse generation	23	9
9	Signal for pulse generation	25	11
10	Signal for pulse generation	26	51

Table 1: Wiring scheme

Other pins are not used.

Postep25-32 has the same pin out as the PoExtBusOC16-CNC motor outputs so you can simply connect them with the 10-pin flat cable.

Please note that PoExtBusOC16-CNC does not support error inputs for status feedback. Pin 7 is connected to GND.

Pin	Function
1	nEnable (0=enable, 1=disable)
3	direction
5	step
7	GND
2, 4, 6, 8, 10	GND
9	Not connected





Figure 5: Postep25-32 connected to PoExtBusOC16-CNC

4. Configuration with PoKeys device

The PoExtBusOC16-CNC functions as an external pulse generator without I/O capability. The following sections provide instructions on how to configure it for operation with Mach3, Mach4 plugins and in standalone operation with the PoKeys device.

Motor enable signal is assumed to be connected to pin 1 of the PoKeys device. This can be changed to a different pin if required.

PoKeys Mach4 plugin

First, the PoKeys device needs to be configured for operation with the Mach4 plugin. If this hasn't been done already, follow the Mach4 plugin instructions when adding the PoKeys57U or PoKeys57E device to plugin configuration. In the new device wizard, set the Pulse engine options to 'External 8ch without IO'.

Set the following Pulse engine settings in the device configuration dialog in the plugin:

- Pulse engine configuration: External 8ch without IO
- Enable out for motor 1: select 'Pin 1'


	Enable out	Inv. en.	Limit-	Inv.-	Limit+	Inv.+	Home	Inv.H	On home	
Motor 0	Pin 1		Disabled		Disabled		Disabled		--	--
Motor 1	Ext. dedicated		Disabled		Disabled		Disabled		--	--
Motor 2	Ext. dedicated		Disabled		Disabled		Disabled		--	--
Motor 3	Ext. dedicated		Disabled		Disabled		Disabled		--	--
Motor 4	Ext. dedicated		Disabled		Disabled		Disabled		--	--
Motor 5	Ext. dedicated		Disabled		Disabled		Disabled		--	--
Motor 6	Ext. dedicated		Disabled		Disabled		Disabled		--	--
Motor 7	Ext. dedicated		Disabled		Disabled		Disabled		--	--

PoKeys Mach3 plugin


First, the PoKeys device needs to be configured for operation with Mach3 plugin. If this hasn't been done already, follow the Mach3 plugin instructions when adding the PoKeys57U or PoKeys57E device to plugin configuration.

Once the PoKeys device is configured, set the following settings:

- Pulse engine settings:
 - o Pulse engine configuration: **External 6ch without IO**




- PoKeys mapping settings:
 - o Set function of pin 1 (motor enable signal) to 'Output'
 - o Select 'Output Enable1' from the options in the IO column
 - o Clear 'Invert' check box



Standalone operation

Use PoKeys software to configure the device for a standalone operation.


First, configure pin 1 (motor enable output) as 'Digital output'. Click 'Send to device'.




Then, open Pulse engine settings follow these steps:

- Release the settings lock by clicking 'Lock settings'. The dialog will be asking you whether you want to load default settings. Confirm with 'Yes'
- Select 'External' in Pulse engine generator options and uncheck the 'Extended IO' check box
- Select 8 channels in Pulse engine generator options
- Select pin 1 in 'Axis enable output on pin'
- Click 'Save configuration'

To test the operation of the device, switch Pulse engine into 'Running' mode (by clicking 'Running' square') and use the +/- jogging buttons for the target axis. The default jog speed is 1 % of the maximum speed - use the slider at the bottom to adjust the jogging speed.



PCB dimensions and mounting holes

5. Grant of license

The material contained in this release is licensed, not sold. PoLabs grants a license to the person who is using any compatible PoLabs product, subject to the conditions listed below.

1. Access

The licensee agrees to allow access to this manual only to persons who have been informed of and agree to abide by these conditions.

2. Usage

The information in this release is for use only with PoLabs products.

3. Copyright

PoLabs claims the copyright of, and retains the rights to, all material (software, documents etc) contained in this release. You may copy and distribute the entire release in its original state, but must not copy individual items within the release other than for backup purposes.

4. Liability

PoLabs and its agents shall not be liable for any loss or damage, howsoever caused, related to the use of PoLabs equipment or software, unless excluded by statute.

5. Fitness for purpose

No two applications are the same, so PoLabs cannot guarantee that its equipment or software is suitable for a given application. It is therefore the user's responsibility to ensure that the product is suitable for the user's application.

6. Mission Critical applications

Because the software runs on a computer that may be running other software products, and may be subject to interference from these other products, this license specifically excludes usage in 'mission critical' applications, for example life support systems.

7. Errors

This manual was continuously monitored for errors during production; however the user is responsible for error checking the manual once it is used.

8. Support

There could be errors in these manual, but if you found some, please contact our technical support staff, who will try to fix the problem within a reasonable time.

9. Upgrades

We provide upgrades, free of charge, from our web site at www.poscope.com. We reserve the right to charge for updates or replacements sent out on physical media.

10. Trademarks

Windows is a registered trademark of Microsoft Corporation. PoKeys, PoKeys55, PoKeys56U, PoKeys56E, PoKeys57E, PoExtension, PoScope, PoLabs and others are internationally registered trademarks.

Support: www.poscope.com